

**Self service hotel - installation instructions  
with automation**





- A** rooms with automation  
 GS-165 - installation under plaster  
 GS-165N - installation on plaster


- B** rooms without automation  
 GS-280K - installation under plaster  
 GS-270K - installation on plaster

- W** entrance to the building  
 GS-280K - installation under plaster  
 GS-270K - installation on plaster


- P** other transitions opened with card  
 GS-280 - installation under plaster  
 GS-270 - installation on plaster



DS-2410 controller with 230 / 12V 2A power supply



Staff cards can open all doors



keyboard card readers



GS-280K installation under plaster



GS-270K installation on plaster



holder with temperature sensor  
card readers




DS-2410 controller



GS-280 installation under plaster




GS-270 installation on plaster



holder should be mounted in height about 115 cm

the reader should be mounted on height about 105 cm




**Attention:**

If the walls in the building are thin (10 - 12 cm) reader and holder cannot be mounted on both sides walls facing each other exactly. The card reading range is 5-10 cm so readers may interfere with each other. We recommend that they be moved about 20 cm.


**BASIC VERSION**

UTP 8 x 0,5 + LY 2 x 1  
to the controller DS-2410




**AIR CONDITIONING AND HEATING FURNACE CONTROL**

UTP 8 x 0,5 + LY 2 x 1  
to the controller DS-2410




**CENTRAL HEATING AND AIR CONDITIONING CONTROL**


UTP 8 x 0,5 + LY 2 x 1  
to the controller DS-2410




**hotel room without automation (B) or entrance (W)**




**GS-280K**



**GS-270K**



**other doors only open with card (P)**



**GS-280**



**GS-270**




the door from the outside should have a fixed knob, from the inside the handle



The door must be fitted with NC electric strike (closed without voltage connected)  
From the outside, the door should have a knob, on the inside of the door handle.  
This solution ensures evacuation in the event of a fire and you don't have to use emergency buttons.  
We recommend leaving the locks with a key opening.  
In an emergency (no 230V voltage) it will be possible to open the door with a key.

**RESERVE POWER SUPPLY**

all devices can be connected to a UPS with a battery. The system will work after switching off 230V.









**Program "Hotel\_M" version for Windows**


**DS-2410 controller with power supply**



**GS-165 - reader - installation under plaster**





Holder





**GS-165N - reader - mounting on plaster**





Holder




**GS-280K - installation under plaster**




**GS-270K - mounting on plaster**




## GS-280 - installation under plaster



## GS-270 - installation on plaster



## NC electric strike (normally closed) 12V DC 0.4A



## Proximity cards - white with printed number



## Relay - switching off the heating, air conditioning



## router TP-LINK





The controller packaging contains a test card.

It is entered into the controller's memory with permission to open all 8 doors.  
Please connect a test card to each GS controller after connecting it  
If the cables are connected correctly, the passage should open.

This way you can check the entire installation without a computer.

After starting Hotel\_M, please select the Configuration function  
and after connecting to the controller click the Delete cards button



The test card number will be deleted from the controller memory.


---

**GS-165 / GS-165N - connections**



there is a test card in the controller housing,  
which opens all passages  
(the system can be checked without connecting a computer)

GS-165 controllers can be connected to all 8 lines







# GS-280K / GS-270K





# BUILDING ENTRY DOORS GS-280K / GS-270K



**BUILDING ENTRY DOORS**


the connection shown in the drawing can be used when connecting the entrance door this will increase the security of the installation the door will not open even if the reader is completely destroyed

**GS-280 / GS-270**





2 wires connected and close to the test card



4 wires connected and close-up of a test card

